

ANTI-SPY PHONE

1. SET THE A/C POWER SUPPLY FOR THE PROPER VOLTAGE IN YOUR AREA (ADAPTER MAY BE NECESSARY). PLUG POWER SUPPLY INTO BACK OF TELEPHONE AND CONNECT A/C POWER. CONNECT PHONE TO TELEPHONE LINE (IT MAY BE NECESSARY TO USE ENCLOSED ADAPTER).

2. TO ACTIVATE THE LINE VOLTAGE DISPLAY, SLIDE RED POWER SWITCH (#6) UP. SECURITY SWITCH (#9) SHOULD BE IN THE LEFT POSITION. ALL 3 SLIDE CONTROLS (A, B, C) ON TOP OF THE PHONE SHOULD BE IN THE FORWARD POSITION. DIGITAL METER (#4) SHOULD NOW DISPLAY ON HOOK LINE VOLTAGE (IN U.S.A. COMMON READING 46-50). UNDER 46 MAY INDICATE A PARALLEL WIRE TAP. LIFT HANDSET, DIAL TONE WILL BE HEARD. THE GREEN EXTENSION MONITOR LIGHT (#1) SHOULD NOW LIGHT. IF LIGHT DOES NOT GO ON, ADJUST LEFT WELL SCREW (#11) UNTIL LIGHT BEGINS TO GLOW. IF DURING A PHONE CONVERSATION THIS LIGHT EXTINGUISHES, THIS WILL INDICATE THAT A PARALLEL TAPE RECORDING OR EXTENSION DEVICE HAS BEEN ATTACHED TO YOUR LINE. THE DIGITAL METER (#4) NOW SHOULD DISPLAY AN OFF HOOK LINE VOLTAGE (IN U.S.A. COMMON 5-10). READING ABOVE 16 MAY INDICATE THE PRESENCE OF SERIES WIRE TAP. IN ORDER TO DETERMINE THE PROPER VOLTAGE FOR YOUR TELEPHONE, DO ONE OF THE FOLLOWING:
 - A) CALL YOUR PHONE COMPANY (PRIVATE OR PUBLIC).
 - B) CHECK OTHER PHONES IN YOUR AREA WITH YOUR ANTI-SPY PHONE I.E. NEIGHBORING HOUSE OR OFFICE.DO NOT USE AN EXTENSION OF THE SAME LINE FOR VERIFICATION OF PROPER VOLTAGE.

3. TO ACTIVATE SECURITY FEATURE SLIDE THE SECURITY SWITCH (#9), TO THE "ON" POSITION. LIFT HAND-SET OFF HOOK. THE RED SECURITY LT(11) SHOULD GLOW. NOTE THE LINE BALANCE CONTROL (B) SHOULD BE COMPLETELY FORWARD. IF THE LIGHT DOES NOT GO ON, ADJUST RIGHT WELL SCREW (#10) UNTIL LIGHT GLOWS. LISTEN FOR A DIAL TONE, SLOWLY SLIDE LINE BALANCE CONTROL (B) BACKWARD UNTIL THE DIAL TONE IS LOST. A CLICK WILL BE HEARD IN THE RECEIVER AT THIS POINT. NOW MOVE THE LINE BALANCE CONTROL SLIGHTLY FORWARD. HANG UP THE PHONE AND THEN PICK IT UP, A DIAL TONE SHOULD BE HEARD. NOTE FOR MAXIMUM SECURITY IN DETECTING AND DEFEATING VOLTAGE ACTIVATED WIRE TAPS, BALANCE CONTROL SHOULD BE AS FAR BACKWARD AS POSSIBLE WHILE STILL MAINTAINING A DIAL TONE. A BALANCE LINE VOLTAGE READING SHOULD THEN BE NOTED. ANY DEVIATION BY MORE THAN .3 VOLTS MAY INDICATE A WIRE TAP DEVICE. IF DURING THE COURSE OF A PHONE CONVERSATION IN THE SECURITY "ON" POSITION, A PARALLEL WIRE TAP IS INTRODUCED ON THE LINE OR AN EXTENSION PHONE IS LIFTED, YOUR ANTI-SPY PHONE WILL GO TOTALLY DEAD, AND THE VOLTAGE METER WILL DISPLAY APPROXIMATELY 50 PERCENT OF THE NORMAL BALANCE LINE VOLTAGE.

EXHIBIT

999